



Corinthian Marble

403 Fleming Road, Charleston, SC 29412
(843) 795-4169 Fax (843) 795-1173

Tub Preparation

Thank you for ordering a tub from us. Here are a few tips to make the installation most successful:

Floor - The floor should be level. No other special preparation is necessary.

Drain – We will put your tub in place and cut a hole in the floor for the drain, if needed.

Tub installation - We will level your tub and frame the support structure.

Skirt framing - We normally locate skirt framing about 1^{1/2}” inside the edge of the tub deck – this will allow sufficient reveal to the tub deck when we place the skirt.

Whirlpool Considerations:

Electrical - Our motor comes with a pigtail for a standard 110 VAC outlet. We recommend a 20 amp circuit. Building code requires a GFCI circuit. Usually a home run to a GFCI breaker is provided with a duplex outlet under the tub deck.

Motor – Building codes require that you provide service access to the hydrobath motor pump. One of the easiest and most attractive solutions is for us to install the tub skirt as a removable panel.

Testing – We provide a final test of the system before assembling the tub skirt. This step requires power and water at the tub.

Please call with any questions.